ΗΙΟΚΙ

SWITCH MAINFRAME SW1001, SW1002



Packed with Features to Ensure Accuracy in Battery Measurements

- O Circuit design friendly for impedance measurements that minimize errors between channels (Effect: 0.01% f.s.*)
- O For OCV measurement, internal resistance measurement, and external potential measurement of battery cells
- O Measure battery modules up to 60 V DC
- O Switch between voltmeter and battery tester while testing
- O Built-in short-circuit protection fuse for each channel



Multi-channel Battery Testing

Combine the SW1001 or SW1002 with a battery testing instrument to measure a battery cell's OCV (open circuit voltage), internal resistance, reaction resistance at low frequency, Cole-Cole plot, and external potential on multiple channels.

SW1001




3 Slots 2-wire: 66 channels; 4-wire: 33 channels; 4-terminal pair: 18 channels (Max. number of channels)

SW1002



12 Slots 2-wire: 264 channels; 4-wire: 132 channels; 4-terminal pair: 72 channels (Max. number of channels)



Connect Up to Two Measuring Instruments with Different Functions

Switch between two types of measuring instruments to perform a variety of measurements.*

Switch between PRECISION DC VOLTMETER DM7276 and BATTERY IMPEDANCE Configuration Example METER BT4560 10-0 SW1002 120,000 TRG -Ô 0 Ò 0 3.85327 DM7276 BT4560 Cell OCV measurements Cell internal resistance measurements External potential measurements Cole-Cole plot measurements between electrode and case * One 2-wire module and one 4-wire module or 4-terminal pair (BNC) module can be used together (see page 7). Only one channel can be measured at a time. Two modules cannot be used at the same time to measure multiple channels.

Battery Measurement Supported by Exclusive PC Application

Use the free, downloadable PC application to perform various measurements easily.*

OCV Measurement function SW1001Appli - Basic m le(M) Set(S) Tools(T) Language(L) Help(H) File(F) Mo dV/Last 1hr V V 1st data dV CH [V] [mV] [mV/day] [mV/hr] [V] 3 782930 -0.015 1 +03 782915E+00 -1201-28.7992 +03.782915E+00 3.782932 -0.017 -32.638 -1.361


Logging function

| CH1: | CH2: | CH3: | Single measurement |
|--|---|---------------------------------------|--|
| R 1.3202E-003 Ω | R 1.3137E-003 Ω | R 1.3171E-003 Ω | Start III (no. |
| V 3.73378E+000 V | V 3.72299E+000 V | V 3.72855E+000 V | |
| CH4: | CH5: | CH6: | See Use actual value |
| R 1.2819E-003 Ω | R 1.3139E-003 Ω | R 1.2788E-003 Ω | |
| V 3.66999E+000 V | V 3.72332E+000 V | V 3.66476E+000 V | |
| CH7: | CH8: | CH9: | Olear social V value |
| R 1.2821E-003 Ω | R 1.2757E-003 Ω | R 1.2790E-003 Ω | |
| V 3.67032E+000 V | V 3.65953E+000 V | V 3.66509E+000 V | |
| CH10: | CH11: | CH12: | E Ster |
| R 1.2725E-003 Ω | R 1.2759E-003 Ω | R 1.3294E-003 Ω | |
| V 3.65429E+000 V | V 3.65986E+000 V | V 3.74906E+000 V | |
| CH13: | CH14: | CH15: | III Faunt |
| R 1.2727E-003 Ω | R 1.2976E-003 Ω | R 1.3296E-003 Ω | Interval: Masc |
| V 3.65462E+000 V | V 3.69607E+000 V | V 3.74939E+000 V | Counti |
| CH16: | CH17: | CH18: | Start: |
| R 1.2945E-003 Ω | R 1.2978E-003 Ω | R 1.2913E-003 Ω | |
| V 3.69083E+000 V | V 3.69640E+000 V | V 3.68560E+000 V | |
| CH19: | CH20: | CH21: | Elapsed Time: |
| R 1.2947E-003 Ω | R 1.2882E-003 Ω | R 1.2915E-003 Ω | |
| V 3.69116E+000 V | V 3.68037E+000 V | V 3.68593E+000 V | |
| CH22: R 1.2850E-003 Ω V 3.67513E+000 V | | | Disky 0 |
| Modelt SW1001 | Rument Subsect Distance Co Madet 873562 Madeit | Measurement CH Start: 1 End: 22 | STOPPED |

Use in combination with supported measurement instruments to perform logging measurements (Interval setting: 1 second to 60 minutes) for up to 264 channels. The judgment function makes it easy to determine the channel on which an abnormality occurred.

Enjoy basic functions as well as a newly added dedicated OCV measurement function. This allows you to measure initial voltage, voltage drops, voltage drop rate (mV/day), and the latest voltage drop rate (mV/hour) in addition to OCV measurement values.

A judgment function is also included, making it easy to determine which battery cell is experiencing aging defects.



Use in combination with the BT4560 or the IM3590 to perform multi-channel Cole-Cole plot measurements.

Allows testing to be performed efficiently for R&D and quality assurance.

*Measurement control supported measuring instruments: DM7275, DM7276, BT3561A, BT3562A, BT3563A, BT3562, BT3563, 3561, BT4560, IM3590, RM3545, RM3544-01 *Save measurement data in CSV file format. •Create save files for each channel. •RS-232C/USB/LAN supported (matching the communication function of the connected device).

LabVIEW[®] Compatibility

Build a measurement system with your LabVIEW® software and our LabVIEW® driver.*


Download the LabVIEW® driver from the HIOKI website at www. hioki.com.

*LabVIEW® is a trademark of National Instruments Corporation.


| HIOKI products compatible with LabVIEW drivers (As of October 2019) | | | | | | | | | |
|--|----|----------------|----|--|--|--|--|--|--|
| SW1001, SW1002 | OK | DM7275, DM7276 | OK | | | | | | |
| BT3561A, BT3562A, BT3563A | OK | 3561 | NG | | | | | | |
| BT4560 | OK | IM3590 | OK | | | | | | |
| RM3545 | OK | RM3544-01 | OK | | | | | | |

Circuit Design for Impedance Measurements

The effect on the detection signal is reduced by canceling the magnetic flux of the AC measurement current and separating the source from the sense.




With the 4-terminal method, magnetic flux is generated from the AC measurement current. Further, the magnetic flux generates an eddy current in the surrounding metal, and the magnetic flux from that eddy current affects the detection signal, resulting in errors in measurement values.



Error in Measurement Values between Channels/Slots Due to Use of Switching System

Example of measurement with BT3562A

Measurement conditions: 3 m Ω range, 0 Ω measurement, after zero adjustment by direct connection




From the measurement results ...

Example of measurement with BT4560

Measurement conditions: RX function, 3 mΩ range, 1 kHz, 0 Ω measurement, after zero adjustment by direct connection






Little error between when a switch is used or not used. (direct connection of measurement instrument) Little error between channels. Little error between slots.

Reliable measurement with little effect from eddy currents

Example of Connection Cables and Supported Measurement Instruments



Choose from Two Types of Multiplexer Modules

MULTIPLEXER MODULE SW9001

This module supports 2-wire/4-wire configurations. Channel switching can be performed in 11 ms (excluding communication, command processing time, and contact bounce).



| Wiring Method | No. of Channels | | | Used Signals | | |
|---------------|--------------------------|------------|---------|----------------|---------------------|--|
| 2-wire | 22 | Sei | nse | CH 1 to CH 22 | | |
| 4-wire | 11 | Source | | CH · | 1 to CH 11 | |
| 4-wire | | Sei | nse | CH 12 to CH 22 | | |
| | Connected Meas struments | uring | Ter | minal | Connection Cable | |
| PRECISION DO | M7276 | TERMINAL 1 | | L4930 | | |
| BATTERY H | 62A | TERN | /INAL 2 | L2108 | | |

MULTIPLEXER MODULE SW9002

This module supports 4-terminal pair configuration for use in combination with BT4560 and IM3590. 2-wire measurement is also possible (Sense only). Channel switching can be performed in 11 ms (excluding communication, command processing time, and contact bounce).



| Wiring Method | No. of Channels | Signa | Signal Type | | d Signals | |
|-----------------|---|--------|-------------|---------------------|---------------------|--|
| 2-wire | 6 | Sei | nse | Sense | CH 1 to CH 6 | |
| | | Source | | Source | CH 1 to CH 6 | |
| 4-terminal pair | 6 | Return | | Return CH 1 to CH 6 | | |
| | | Sei | nse | Sense CH 1 to CH 6 | | |
| | of Connected Measurement Instruments | | | rminal | Connection Cable | |
| PRECISION DO | PRECISION DC VOLTMETER DM7276 | | | | L4930 | |
| BATTERY IMPE | DANCE METER | BT4560 | TERM | AINAL 3 | L2004 | |

Examples of Switching Measurement Time (Use in combination with SW1002 to measure the actual time for scan measurements.)*

* Communication with SW1002 via USB.

| Module | Measuring Instrument | Function | Measurement Speed | No. of Channels | Delay Time | Scan Time (All Channels) | Conditions |
|--------|-------------------------|----------|----------------------|--------------------|------------|---------------------------|--|
| | | | 0.02 PLC | 22 | 0 ms | 0.45 s (Approx. 20 ms/CH) | Communication with DM7276 via USB |
| | DM7276 | V | FAST | 22 | 0 ms | 0.85 s (Approx. 39 ms/CH) | Contact check OFF |
| SW9001 | | | MEDIUM | 22 | 0 ms | 4.9 s (Approx. 223 ms/CH) | Contact check of f |
| | BT3562A | ΩV | EX. FAST | 11 | 10 ms | 0.45 s (Approx. 41 ms/CH) | Communication with BT3562A |
| | D13302A | 12 V | MEDIUM | 11 | 10 ms | 1.1 s (Approx. 100 ms/CH) | via RS-232C (38,400 bps) |
| | | | FAST | 6 | 0 ms | 1.0 s (Approx. 167 ms/CH) | Communication with BT4560 via USB |
| SW9002 | BT4560 | RX | MEDIUM | 6 | 0 ms | 1.2 s (Approx. 200 ms/CH) | (9600 bps) Measurement frequency: 1 kHz |

Control Interface/Useful Functions

Channel switching is controlled by the communication interface. LAN/USB/RS-232C interfaces are supported.

Rear Interfaces



Communication I/F: LAN/USB/RS-232C (HOST) Transmission of communication commands to measurement instruments: RS-232C (INSTRUMENT) For scanner control: EXT. I/O^{*1}

EXT. I/O Signal Table


| | 0 | | | |
|-----|-------------|-----|-----------------------------------|-------|
| Pin | Signal Name | I/O | Function | Logic |
| 1 | SCAN | IN | Start/advance scan | Edge |
| 2 | (Reserved) | IN | - | - |
| 3 | ISO_5V | - | Isolated power +5 V (-5 V) output | - |
| 4 | CLOSE | OUT | Complete channel closing | Pulse |
| 5 | (Reserved) | OUT | - | - |
| 6 | SCAN RESET | IN | Reset scan operation | Edge |
| 7 | (Reserved) | IN | - | - |
| 8 | ISO_COM | - | Isolated power common | - |
| 9 | (Reserved) | OUT | - | - |
| | | | | |

*1 9-pin D-sub (Female #4-40 screw), Input: Photocoupler isolated non-voltage contact input, Output: Photocoupler isolated open drain output

Communication Command Transmission Function Reduces the Number of PC Ports Needed

Normally, PC control requires two ports: one communication port for switching and one for the measuring instrument. By using the communication command transmission function on the SW1001 and SW1002, the switch mainframe can transfer control commands from the PC to the measuring instrument (and responses can be received from the device). This allows you to reduce the number of communication ports used on the measuring instrument.^{*2}

*2 The measuring instrument is connected with the RS-232C. Only one instrument is supported (one port).



Control Command Transmission from PC

Command transfered to Measuring Instrument

Scan Function

This function switches between channels in order based on the scan list registered in advance.

The switch mainframe and the EXT. I/O of the measuring instrument are connected. With the scan function, channel switching and trigger measurement can be synced for continuous scanning. *3

*3 To obtain the measurement value, use the data output function or the memory function on the measuring instruments.



Use the PC App

Relay Open/Close Count Function

The number of times each relay opens/ closes can be confirmed on the PC application. This allows you to estimate the service life of a relay.

| | | | nformatior | | | | | | | | | |
|---|-----------|--------|------------|---------|------------|--------|--------|--------|--------|--------|--------|----|
| | Module | Model | Serial No. | Version | Relay(max) | Relay1 | Relay2 | Relay3 | Relay4 | Relay5 | Relay6 | Re |
| • | MAINFLAME | SW1002 | 180610765 | V1.00 | | | | | | | | |
| | SLOT1 | SW9001 | 180610772 | | 57 | 57 | 57 | 57 | 57 | 57 | 57 | 52 |
| | SLOT2 | SW9002 | 180610773 | | 31 | 29 | 28 | 27 | 27 | 27 | 27 | 0 |
| | SLOT3 | | | | | | | | | | | |
| | SLOT4 | - | | | | | | | | | | |
| | SLOT5 | 573 | | | | | | | | | | |
| | SLOT6 | 120 | | | | | | | | | | |

Connector Pin Layout for Measurement of Multiplexer Module

| 50-pin D-sub | SW9 | 001 Co | onr | necto | r signa | al ta | able | | | |
|---|------------|------------|------|-----------|------------|-------|---------|------------|--------|----|
| (Male #4-40 screw UNC) | Pin | Signa | ιl | Pin | Signa | ιI | Pin | Signa | ıl | |
| | 17 | Shield | b | 33 | CH11 | Н | 50 | CH11 | L | |
| $\begin{pmatrix} 17 \\ 0 33 \\ 0 \end{pmatrix}$ | 16 | CH10 | Н | 32 | CH9 | L | 49 | CH10 | L | |
| | 15 | CH9 | Н | 31 | CH8 | Н | 48 | CH8 | L | |
| | 14 | CH7 | Н | 30 | CH6 | L | 47 | CH7 | L | |
| 0 0 | 13 | CH6 | Н | 29 | CH5 | Н | 46 | CH5 | L | |
| | 12 | CH4 | Н | 28 | СНЗ | L | 45 | CH4 | L | |
| | 11 | СНЗ | Н | 27 | CH2 | Н | 44 | CH2 | L | |
| | 10 | CH1 | Н | 26 | Shield | b | 43 | CH1 | L | |
| | 9 | Shield | k | 25 | CH22 | Н | 42 | CH22 | L | |
| | 8 | CH21 | Н | 24 | CH20 | L | 41 | CH21 | L | |
| | 7 | CH20 | Н | 23 | CH19 | Н | 40 | CH19 | L | |
| 0 0 | 6 | CH18 | Н | 22 | CH17 | L | 39 | CH18 | L | |
| 0 0 | 5 | CH17 | Н | 21 | CH16 | Н | 38 | CH16 | L | |
| | 4 | CH15 | Н | 20 | CH14 | L | 37 | CH15 | L | |
| | 3 | CH14 | Н | 19 | CH13 | Н | 36 | CH13 | L | |
| | 2 | CH12 | Н | 18 | Shield | b | 35 | CH12 | L | |
| 0 18 0 1 18 34 | 1 | Shield | k | - | - | | 34 | Shield | t | |
| | ith a 4-wi | re system, | char | nnel n an | id channel | n+11 | are Sou | urce/Sense | e pair | s. |

37-pin D-sub

SW9002 Connector signal table

| 37-pin D-sub | | | | | <u> </u> | | | |
|------------------------|-----|--------|-------|---|----------|--------|------|---|
| (Male #4-40 screw UNC) | Pin | S | ignal | | Pin | Sig | gnal | |
| (19 37) | 19 | Return | CH6 | L | 37 | Source | CH6 | L |
| | 18 | Return | CH5 | L | 36 | Source | CH5 | L |
| | 17 | Return | CH4 | L | 35 | Source | CH4 | L |
| | 16 | Return | CH3 | L | 34 | Source | СНЗ | L |
| | 15 | Return | CH2 | L | 33 | Source | CH2 | L |
| | 14 | Return | CH1 | L | 32 | Source | CH1 | L |
| | 13 | Source | CH1 | Н | 31 | Return | CH1 | Н |
| | 12 | Source | CH2 | Н | 30 | Return | CH2 | Н |
| | 11 | Source | CH3 | Н | 29 | Return | СНЗ | Н |
| | 10 | Source | CH4 | Н | 28 | Return | CH4 | Н |
| | 9 | Source | CH5 | Н | 27 | Return | CH5 | Н |
| | 8 | Source | CH6 | Н | 26 | Return | CH6 | Н |
| | 7 | S | hield | | 25 | Sense | CH1 | L |
| | 6 | Sense | CH1 | Н | 24 | Sense | CH2 | L |
| | 5 | Sense | CH2 | Н | 23 | Sense | СНЗ | L |
| | 4 | Sense | СНЗ | Н | 22 | Sense | CH4 | L |
| | 3 | Sense | CH4 | Н | 21 | Sense | CH5 | L |
| | 2 | Sense | CH5 | Н | 20 | Sense | CH6 | L |
| | 1 | Sense | CH6 | Н | | | | |

Please prepare measurement cables (multiplexer module - measurement target). Connectors For SW9001: DD-50SF-N, For SW9002: DC-37SF-N (Manufactured by Japan Aviation Electronics Industry, Ltd.) When a 2-wire system is used, only Sense CH1 to CH6 are enabled.

Effects when Used in Combination with a Measurement Instrument

Combined measurement accuracy = Accuracy of measurement instrument + Combined effects

SW9001

| BT3561A, BT3562A, BT3563A, BT3562, BT3563 (connected with L2108) | | | | | | | |
|--|---------------------------|--|--|--|--|--|--|
| Range | Effect | Conditions and Remarks | | | | | |
| R 3 mΩ | ±0.1% f.s. | - | | | | | |
| R 30 mΩ to 300 Ω | ±0.03% f.s. | - | | | | | |
| R 3000 Ω *1 | ±3.0% rdg. ±0.03% f.s. | Measurement abnormality detection not possible (BT3562, BT3563) | | | | | |
| Entire V range | $\pm5~\mu\mathrm{V}$ *2 | After stabilization of temperature in usage environment Within 1 minute of contact closing | | | | | |

| 3561 (connected w | 3561 (connected with L2108) | | | | | | | | |
|-------------------|-----------------------------|--|--|--|--|--|--|--|--|
| Range | Effect | Conditions and Remarks | | | | | | | |
| Entire R range | ±0.03% f.s. | - | | | | | | | |
| Entire V range | $\pm5~\mu\mathrm{V}$ *2 | After stabilization of temperature in usage environment Within 1 minute of contact closing | | | | | | | |

| DM7275, DM7276 (connected with L4930) | | | | | | | |
|---------------------------------------|-----------------|--|--|--|--|--|--|
| Range | Effect | Conditions and Remarks | | | | | |
| Entire V range | $\pm7~\mu V$ *2 | After stabilization of temperature in usage environment Within 1 minute of contact closing | | | | | |

List of possible combinations when using two measuring instruments together

One 2-wire module + one 4-wire module, or one 2-wire module + one 4-terminal pair module can be used together.

| 1st Module | 2nd Module |
|------------------|-----------------|
| | BT3562A or 3561 |
| DM7275 or DM7276 | BT4560 |
| | IM3590 |

Combinations of two 2-wire modules, two 4-wire modules, or one 4-wire module + one 4-terminal pair module are not possible.

S/M0002

| 2003005 | | | | |
|-------------------------------|---------------------------------|----------------------------------|---|--|
| BT4560 (connected with L2004) | | | | |
| | Effect | | | |
| Range | Freq. Range 0.1 Hz to 100 Hz | Freq. Range 110 Hz to 1050 Hz | Conditions and Remarks | |
| 3 mΩ R | ±0.05% f.s. | ±0.1% f.s. | - | |
| 3 mΩ X | ±0.1% f.s. | ±1.0% f.s. | - | |
| 10 mΩ R | ±0.015% f.s. | ±0.03% f.s. | - | |
| 10 mΩ X | ±0.03% f.s. | ±0.3% f.s. | - | |
| 100 mΩ R | ±0.01% f.s. | ±0.01% f.s. | - | |
| 100 mΩ X | ±0.015% f.s. | ±0.03% f.s. | - | |
| Entire V range | ±5 µV *2 | | After stabilization of temperature in usage environment Within 1 minute of contact closing | |

| IM3590 *3 (connected with L2004) | | | |
|----------------------------------|--------------------------------------|--|--|
| Range | Effect | Conditions and Remarks | |
| 100 mΩ to 10 Ω | IM3590 measurement accuracy ×1 | DC, 0.001 Hz to 10.000 kHz | |
| 100 Ω to 10 kΩ | IM3590 measurement accuracy ×3 | DC, 0.001 Hz to 10.000 kHz Impedance upper limit 10 k Ω | |
| DM7275, DM7276 (c | onnected with L4930) | | |
| Range | Effect | Conditions and Remarks | |
| Entire V range | ±7 μV *2 | After stabilization of temperature in usage environment Within 1 minute of contact closing | |

*1 Measurement anomaly detection function not available in the 3000 Ω range of the BT3562 and BT3563.

*2 The effect of voltage measurement includes the offset voltage of the basic specifications.

*3 The effect when used in combination with the IM3590 is a reference value. It is not a guaranteed value.

SWITCH MAINFRAME SW1001. SWITCH MAINFRAME SW1002 Specifications *1

| Slots | 3 slots (SW1001), 12 slots (SW1002) | - Functions | Channel switching, wiring method, scan function, communication comman transmission, channel delay, shield switching |
|--|--|---|---|
| Supported modules MULTIPLEXER MODULE SW9001 (2-wire/4-wire) MULTIPLEXER MODULE SW9002 (4-terminal pair) | MULTIPLEVED MODULE SW0001 (2 mins) | | |
| | | Display | Power LED, Error LED, Remote LED |
| | Compliance standards | Safety: EN61010, EMC: EN61326 Class A | |
| Connectible instruments | Max. 2 units 2-wire x 1 + 4-wire x 1, or 2-wire x 1 + 4-terminal pair x 1 | Operating temperature and humidity range | 0°C to 40°C (32°F to 104°F), 80% RH or less (no condensation) |
| Analog bus terminal TERMINAL 1: Banana terminal (2-wire) TERMINAL 2: Banana terminal (4-wire) TERMINAL 3: BNC terminal (4-terminal pair) | Storage temperature and humidity range | -10°C to 50°C (14°F to 122°F), 80% RH or less (no condensation) | |
| | Operating environment | Indoors, Pollution Degree 2, altitude up to 2000 m (6562.20 ft) | |
| | Power supply | 100 to 240 V AC / 30 VA (50/60 Hz) | |
| Maximum input voltage | 60 V DC *2, 30 V AC rms, 42.4 V peak | Dimensions and mass | Approx. 215 mm (8.46 in) W x 132 mm (5.20 in) H x 420 mm (16.54 in) D, Approx. 3.7 kg (130.5 oz) (SW1001) Approx. 430 mm (16.93 in) W x 132 mm (5.20 in) H x 420 mm (16.54 in) D, Approx. 6.0 kg (211.6 oz) (SW1002) |
| Maximum rated voltage to ground | 60 V DC | | |
| Communication I/F | LAN, USB, RS-232C (for host, for measurement instruments) | | |
| EXT. I/O | SCAN input, SCAN_RESET input, CLOSE output (to control scanner) | Accessories | Power cord x 1, instruction manual x 1, usage precautions x 1, USB driver CD x 1 |

MULTIPLEXER MODULE SW9001 Specifications^{*1}

| Wiring method | 2-wire or 4-wire |
|---------------------------------|---|
| No. of channels | 22 channels (2-wire) / 11 channels (4-wire) |
| Contact method | Armature relays |
| Channel switching time | 11 ms (excluding measurement time) |
| Max. allowable voltage | 60 V DC, 30 V AC rms, 42.4 V peak |
| Max. allowable current | 1 A DC, 1 A AC rms |
| Max. allowable power | 30 W (resistive load) |
| Maximum rated voltage to ground | 60 V DC |
| Offset voltage *3 | 5 µV (TERMINAL 1, TERMINAL 2 Sense) |
| Initial path resistance | Less than 1.5 Ω (when using TERMINAL 1) Less than 0.7 Ω (when using TERMINAL 2, 3) |
| Insulation resistance | 1 G Ω or more between High-Low channels (at 60 V DC) |
| Contact life (reference value) | No load: 50 million times 30 V capacitive load (1.2 μF + 60 $\Omega,$ 500 mA peak): 10 million times |
| Dimensions and mass | Approx. 25.5 mm (1.00 in) W x 110 mm (4.33 in) H x 257 mm (10.12 in) D, Approx. 210 g (7.4 oz) |
| Accessories | Instruction manual x 1 |
| | |

MULTIPLEXER MODULE SW9002 Specifications*1

| Wiring method | 4-terminal pair (6-wire) or 2-wire |
|-----------------------------------|---|
| No. of channels | 6 channels (4-terminal pair) / 6 channels (2-wire) |
| Contact method | Armature relays |
| Channel switching time | 11 ms (excluding measurement time) |
| Max. allowable voltage | 60 V DC, 30 V AC rms, 42.4 V peak |
| Max. allowable current | 1 A DC, 1 A AC rms (Sense) 2 A DC, 2 A AC rms (Source, Return) |
| Max. allowable power | 30 W (resistive load) |
| Maximum rated voltage to ground | 60 V DC |
| Offset voltage *3 | 5 µV (TERMINAL 1, TERMINAL 2 Sense) |
| Initial path resistance | Less than 1.5 Ω (when using TERMINAL 1) Less than 1.0 Ω (when using TERMINAL 2, 3) |
| Insulation resistance | 1 G Ω or more between High-Low channels (at 60 V DC) |
| Contact life (reference value) | No load: 50 million times |
| Dimensions and mass | Approx. 25.5 mm (1.00 in) W x 110 mm (4.33 in) H x 257 mm (10.12 in) D, Approx. 196 g (6.9 oz) |
| Accessories | Instruction manual x 1 |

*1 Product warranty period: 3 years (excluding relays and fuses)

*2 Cannot connect to battery packs in excess of 60 V DC.

*3 The offset value is from within 1 minute of closing the channel. This value is also taken when the temperature of the usage environment is sufficiently stable, and when the instrument has acclimated to that temperature

Lineup



Model No. (Order Code) : SW1001

Module not included with the switch mainframe. Modules must be purchased separately.



Model No. (Order Code) : SW1002


Optional Modules



MULTIPLEXER MODULE SW9001



MULTIPLEXER MODULE SW9002



HIOKI E.E. CORPORATION

HEADQUARTERS

81 Koizumi. Ueda, Nagano 386-1192 Japan https://www.hioki.com/



regional contact information